## *O***PRÍCOS®** Skew Rabbet Planes – Long Fence Rods

05P45.60

Made in Canada

## Installation

Loosen the fence locking knobs and remove the fence. Loosen the fence rods with a 1/4'' wrench, then unscrew and remove the fence rods. Mount the long fence rods into place and snug with wrench. Replace the fence, then retighten the fence knobs.

## **VERÍCAS®** Tools Inc.

814 Proctor Avenue Ogdensburg, New York 13669-2205 USA 1090 Morrison Drive Ottawa, Ontario K2H 1C2 Canada

638 © Veritas Tools Inc. 2009 customerservice@veritastools.com www.veritastools.com INS-388 Rev. B Printed in Canada.